


Shot Clock Operation with 3 button control console 24 or 14 second reset



While shot timer is **not** running press the reset button twice to change between 24 and 14 seconds and vice versa

While shot timer is running press the RESET button to reset to 24 seconds or press both START and RESET together to reset to 14 seconds